

Bevi Standup 2.0 - EU User Guide, Installation & Maintenance Manual

Rev 01 - August 2024

Table of Contents

| Table of Contents | |
|-----------------------------------|----|
| Product Overview | 2 |
| Safety & Regulatory Requirements | 2 |
| Installation Safety | 3 |
| Machine Safety | 3 |
| Consumables | 4 |
| FCC / ISED | 4 |
| Patent Information | 5 |
| Installation Requirements | 5 |
| Space Requirements | 5 |
| Electrical Requirements | 5 |
| Plumbing Requirements | 6 |
| Network Requirements | 6 |
| Installation Instructions | 6 |
| Unpacking and Initial Setup | 6 |
| Install Wizard | 9 |
| Incubation Mode | 10 |
| Maintenance Instructions | 10 |
| Standup 2.0 Operation and Service | 10 |
| Technical Specifications | 11 |
| Revision Table | 13 |



Product Overview

The Bevi Standup 2.0 is an internet-connected water dispenser machine. It provides filtered still, sparkling, ambient and hot water with a variety of flavors and enhancements. Drinks may be poured via the machine touchscreen interface or the touchless dispensing system.

This machine is manufactured by Bevi, which is headquartered at 529 Main St, Charlestown, MA 02129. USA.

Safety & Regulatory Requirements

We have provided important safety messages in this manual for your Bevi. Always read and obey the installation instructions and safety language. If you have questions or concerns please reach out to your Bevi Customer Success Manager, or contact support@bevi.co.

Installation Safety

- Water pipe connections and fixtures directly connected to a potable water supply shall be sized, installed, and maintained in accordance with federal, state, and local codes.
- This appliance must be properly installed on a GFCI protected circuit.
- Maximum water inlet supply pressure must not exceed: 100 PSI (0.7 MPa).
- This appliance is climatic class 0: 20°C (68°F), 50% RH, 9.3°C dew point, 7.3 g/kg water vapor mass in dry air.
- Machine is for indoor use only, 10-32°C (50-90°F).
- This appliance must be placed in a horizontal position.
- **CAUTION**: This appliance contains flammable refrigerant Propane R290. The handling, moving, and use of the water cooler shall be done in a manner so as to avoid either damaging the refrigerant tubing or increasing the risk of a leak.
- This appliance having flammable refrigerant shall not be intended for use in a location of safety egress, such as a hallway or public corridor.
- For proper ventilation, ensure that the appliance has a minimum of ¾-inch clearance around the sides and top of the machine and a minimum of 2-inch clearance on the back of the machine.



Machine Safety

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Appliance is only to be installed in locations where it can be overseen by trained personnel.
- The appliance must not be cleaned by a water jet, and not installed in an area where a water jet could be used.
- Do not store explosive substances such as aerosol cans with a flammable propellant inside the appliance.
- Component parts shall be replaced with like components. Users shall not attempt to replace or service parts of the Standup 2.0 machine unless trained appropriately by Bevi personnel.
- WARNING: BURN HAZARD. The dispenser heats water to a temperature of approximately 190°F (88°C). Water temperatures above 125°F (52°C) can cause severe burns or death from scalding. Children, the disabled and the elderly are at highest risk of being scalded. Children should be supervised by an adult when using this product.
- The maximum loading of each BiB shelf is 20 lbs.
- WARNING: Do not damage the refrigerating circuit
- WARNING: Do not use electrical appliances inside the food/ice storage compartments unless they are of the type recommended by the manufacturer

Consumables

- Only use Bevi branded or approved concentrates with this machine.
- Consumables have an expiration date. At or after an expiration date, the consumable should be removed from the Bevi and disposed of properly.
- It is critical that if leaving the machine unattended for an extended period of time (2-weeks) that the machine undergoes a full cleaning prior to returning to service.



FCC / ISED

- Changes or modifications not expressly approved by Bevi could void the user's authority to operate the equipment.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation
- This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.
- This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s).
 Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
 - Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS sans licence d'Innovation, Sciences et Développement économique Canada. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
- This equipment complies with FCC and ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Patent Information

U.S. Patent No. D998,401, GB Patent No. 2562368



Installation Requirements

Prior to installing the Bevi Standup 2.0, be sure to read, understand, and follow all of the installation safety requirements listed in the Safety and Regulatory Requirements section.

Space Requirements

To provide adequate ventilation, the <u>minimum</u> space required for the Bevi Standup 2.0 is:

o Width: 18.5 inches

o Depth: 23.75 inches

o Height: 69.25 inches

Machine is for indoor use only, 10-32°C (50-90°F).

Electrical Requirements

- Input required is 240 VAC, 50 Hz, 5A
- The Bevi Standup 2.0 is provided with a 10-ft (3-m) power cord. **Do not** use an extension cord to provide electrical power to the machine.
- This appliance must be properly installed on a GFCI protected circuit.

Plumbing Requirements

- Water inlet size: 1/4-inch Push-to-Connect
- Water inlet supply pressure: MAX 0.7 MPA (100 PSI), MIN 0.28 MPA (40 PSI)
- Water pipe connections and fixtures directly connected to a potable water supply shall be sized, installed, and maintained in accordance with federal, state, and local codes.
- NOTE: Bevi Standup 2.0 is equipped with an ASSE 1032-certified backflow preventer device internal to the machine.

Network Requirements

WiFi 802.11b/g/n (2.4 GHz) or Ethernet CAT-5 RJ45 required



Installation Instructions

Unpacking and Initial Setup

⚠ NOTE: <u>Two people</u> are recommended to unpack the machine.

- 1. Remove outer packaging materials by cutting the strapping, removing the cardboard top cap, snapping off the plastic retainer clips, and removing the large flat cardboard side panel. Remove the 4 vertical folded honeycomb supports from the corners of the machine. Unfold the side flaps of the cardboard bottom.
- 2. Carefully tilt the machine to slide the front and rear cardboard pads out from the underside of the machine. Use an appliance cart / hand truck appropriate for moving this size device, positioned behind the machine, to carefully tilt the machine backward to remove the cardboard pad from underneath the center of the machine.





3. Roll the machine toward the front edge of the pallet to allow space behind the rear of the machine.



4. Position an appliance cart / hand truck, appropriate for moving this size device, behind the rear of the machine. Use moving blankets / foam supports together with safety straps to secure the machine to the appliance cart. Keep the protective bag in place over the machine whenever moving it.





5. Carefully tip the machine onto the cart. Roll the cart slowly and carefully off the front edge of the pallet, lowering it softly until the wheels touch the floor. Carefully tip the cart and machine forward until the machine is fully resting on the floor. (**NOTE:** <u>This step may require more than one person</u>)







- 6. If moving the machine unpackaged to its intended installation location, continue to use an appliance cart / hand truck appropriate for moving this type of machine.

 Use moving blankets / foam supports together with safety straps to avoid personal injury and/or damage whenever moving the machine.
 - i) The wheels on the base of the machine should only be used to roll the machine the final few feet into its intended installation position.
- 7. Remove the plastic bag from the machine.
- 8. Remove the power cord from the bag taped to the outside of the machine.
- Plug the power cord into the receptacle at the top rear of the machine. Plug the other end of the power cord into a power receptacle. (NOTE: Circuit should be GFCI protected)
- 10. Flip the power switch located on the top rear of the machine to the ON position. Wait for the product's screen to load in order to continue setup using the Bevi Standup 2.0's Install Wizard.
- 11. Recycle all corrugated packaging material as well as plastic clips and straps. Wherever possible, reuse the pallet for other shipping purposes.



Install Wizard

When powered on for the first time, Bevi Standup 2.0 will enter into the Install Wizard tool to assist with the remainder of the setup. Install Wizard uses the machine's LCD touchscreen display to perform the the following steps:

- Network connection setup (WiFi or ethernet)
- Software updates
- Registering the Bevi Standup 2.0
- Adding a water filter
- Adding a CO2 tank
- Connecting water source & filling the machine with water
- Adding flavors and enhancements

Incubation Mode

Once the Install Wizard is complete, Bevi Standup 2.0 will need time to cool down its refrigeration system. Bevi Standup 2.0 utilizes incubation mode to ensure the machine is properly cooled before users can dispense drinks.



Maintenance Instructions

Access to the service area is restricted to persons having knowledge and practical experience of the appliance. Service technicians will be able to access the service panel using a specific code to unlock the machine.

The machine may be cleaned only as needed using a dry cloth. The appliance should not be cleaned using any form of a water jet.

Standup 2.0 Operation and Service

For more information on how to operate, service, and troubleshoot the Bevi Standup 2.0 machine, visit our partners website.

http://partners.bevi.co





Technical Specifications

| Bevi Model Number | 700-0015 |
|----------------------|--|
| Refrigerant | Propane R290 52.5g |
| Inputs | |
| Electrical | Power: 240 VAC 50 Hz 12A Max Ethernet: CAT-5 RJ45 (Optional) WiFi: 802.11b/g/n Cellular: LTE CAT1 |
| Water Inlet Size | 1/4" Push-to-Connect |
| Water Inlet Pressure | Minimum: 0.28 MPa (40 psi) Maximum: 0.7 MPa (100 psi) |
| Consumables | |
| Flavors | Up to 8 |
| Enhancements | Yes |
| CO2 | Connection: CGA-320 Tank Sizes: 5lb, 10lb, 20lb |
| Water Filter | 3M HF20 |
| Dimensions/Weight | |
| Unpackaged | W 16.5" x D 22" x H 66.25" 240 lbs |
| Packaged | W 31" x D 31" x H 73" 280 lbs |
| | |



| Certifications | | |
|--------------------------------------|--|--|
| Electrical Safety | UL 1951 - Standard for Safety Electric Plumbing Accessories CSA C22.2 No. 120-13 - Refrigeration Equipment UL 399 - Standard for Drinking-Water Coolers UL 499 - Standard for Safety Electric Heating Appliances IEC/EN 60335-1 - Standard for the Safety of Household and Similar Electrical Appliances IEC/EN 60335-2-75 - Standard for the safety of electric commercial dispensing appliances and vending machines for preparation or delivery of food, drinks, and consumer products IEC/EN 60335-2-89 - Particular requirements for commercial refrigerating appliances and ice-makers with an incorporated or remote refrigerant unit or motor-compressor | |
| Sanitation | NSF/ANSI 18 | |
| Electrical Emissions & Compliance | FCC ID: 2AMTV-103838 IC ID: 22810-103838 | |
| Cellular Compliance | EU RED Directive | |
| Patent Information | U.S. Patent No. D998,401 GB Patent No. 2562368 | |



Revision Table

This table will list major revisions of the unit and contain a summary of changes for each revision.

| Revision | Date Effective | Summary of Changes |
|----------|----------------|-------------------------------|
| 01 | September 2024 | Initial release to production |

