


Replacing CO2

When the Bevi is in need of CO2 the sparkling option will be unavailable on the main dispense screen.



Navigate to the Service Panel: Select "Explore" on the Dispense screen, then "Service" on the Ingredients screen. Enter the Service PIN Code:1986 to enter the Service Panel.



Remember: the indicator shows in Red - meaning "OUT", or Yellow indicating less than 20% remaining.

1. Start the CO2 Wizard

To replenish CO2, select the "CO2 Tank" under What are you swapping today?

What are you swapping today?




The CO2 replenishment wizard will walk you through all the steps needed to swap CO2 in a Bevi Standup 2.0

Remember: Once the steps are completed, the "Continue" Button will appear and allow you to move to the next step.




2. Follow the steps on the CO2 replenishment wizard


Remove the current CO2 Tank by following steps 1-4 in the wizard, see image below. Click 'Continue'.




3. Inspect the washer in the CO2 hose is present and fully seated against the brass fitting. Add the new CO2 Tank. Click 'Continue'.



Confirm the new tank size. Click 'Save'.



4. Place a large container under the nozzle and click the play button to purge the system, (this takes about 20 seconds).



NOTE: The play button can be paused to empty the container if needed.

Once complete, select "Finish Swap" to return to the service panel.

Click "Finish Service" in the service panel to return the machine back to the dispense screen.

